
Mingo Custom Woods

2380 County Road K
Colby, KS 67701
(785)462-2200

Jewelry-Closet TMCabinet Installation Instructions For Surface Mounted Cabinets

Read all the instructions before mounting your Jewelry-Closet TMcabinet.

Tools required: (2) 1 ½ Screws
 (2) Sheetrock anchors

STEP #1

Position your Jewelry-Closet TMcabinet on the wall. Mark placement for sheetrock anchors by pushing screws into center of predrilled mounting holes or by using a pencil to mark the center of the mounting holes. See diagram for location of mounting holes. Set cabinet aside.

STEP #2

Place the point of the sheetrock anchor on the marks and screw the sheetrock anchors into the sheetrock using the screwdriver. Anchor face should be flush with sheetrock

STEP #3

Reposition the cabinet and insert the top screw through the cabinet into the sheetrock anchor and tighten. Be sure you have both screws started before you tighten completely so that you can move the cabinet a little if needed to start the bottom screw. Repeat with bottom screw and tighten both screws. Do not over tighten. The screws only need to be snug enough to hold the cabinet against the wall.

NOTE:

If screw holes line up with studs in wall, sheetrock anchors are not needed.

